



图例:

- 1-喷嘴接头Ø10(选配)
- 2-经济器接头Ø22(选配)
- 3-排气温度传感器1/8"NPT
- 4-高压接头1/4"SAE-FLARE
- 5-配压调节电磁阀
- 6-低压接头1/4"SAE-FLARE
- 7-油压接头1/4"SAE-FLARE
- 8-油路接头5/8"SAE-FLARE
- 9-排气截止阀 Ø54 (2-1/8")
- 10-单向阀
- 11-电磁阀板 (有级-无级转换)
- 12-接线盒
- 13-吸(截止)阀 Ø80 (3-1/8")

Key:

- 1-Liquid injection connection $\phi 10$
- 2-Economizer connection $\phi 22$ (option)
- 3-Exhaust temperature sensor 1/8"NPT
- 4-High pressure connection 1/4"SAE-FLARE
- 5-Solenoid valves for part-load operation
- 6-Low pressure connection 1/4"SAE-FLARE
- 7-Oil pressure connection 1/4"SAE-FLARE
- 8-Oil inlet connection 5/8"SAE-FLARE
- 9-Discharge shut-off valve Ø54 (2-1/8")
- 10-Check valve
- 11-Solenoid valve connection (1A-1Z)
- 12-Electrical box
- 13 Suction shut off valve Ø80 (3 1/8")