



型号/Type	Φ i A	Φ i B
SP2L0300/030E	16-5/8"	28-1 1/8"
SP2L0400/040E	16-5/8"	28-1 1/8"
SP2L0500/050E	22-7/8"	28-1 1/8"
SP2L0600/060E	22-7/8"	28-1 1/8"
SP2H0500/050E	16-5/8"	28-1 1/8"
SP2H0600/060E	16-5/8"	28-1 1/8"



视图 I
DETAIL I
1:2



图例:

- 1) 高压进 L 1/4"SAE-FLARE
- 2) 排气温度传感器 1/8"NPT(可选)
- 3) 低压进 L 1/4"SAE-FLARE
- 4) 机油滤 1/4"NPT
- 5) 机油滤加热器
- 6) 机油滤 1/4"NPT
- 7) 油杯 1/8"-18UNEF
- 8) 低压进 L 1/4"SAE-FLARE
- 9) 电气盒
- DL 排气截止阀
- SL 吸气截止阀

Key:

- 1) High pressure 1/4"SAE-FLARE
- 2) Discharge temperature sensor 1/8"NPT(optional)
- 3) Low pressure 1/4"SAE-FLARE
- 4) Oil drain 1/4"NPT
- 5) Oil drain heater
- 6) Oil charging 1/4"NPT
- 7) Oil sight glass
- 8) Plug 1/8"-18UNEF
- 9) Oil level sensor(optional)
- DL Low pressure 1/4"SAE-FLARE
- DL Discharge shut-off valve
- SL Suction shut-off valve